

# NEOWAVE

## Download instructions for the NEOWAVE OTP Manager application for Windows, macOS and Linux

### PRESENTATION / QUICK GUIDE

---

NEOWAVE OTP Manager is an application that allows you to configure and use OTP (One-Time Password) authentication with your Winkeo or Badgeo.

OTP authentication is a multi-factor authentication (MFA) method. It should be used in addition to your password to add a layer of security.

### INSTALLATION

---

#### On Windows :

You have two options for using the application :

1. NeoOTP\_Install.exe : This is an installer, recommended for a clean installation of the application in your environment. Run it and follow the instructions. The application will then be accessible from the Windows Start menu for easy access.
2. NeoOTP.exe : This is the standalone executable file for the application. You can place it on your PC and run it directly to use the application.

#### On macOS :

Open the NeoOTP.dmg file and drag the “NeoOTP” application to your “Applications” folder to install it. You will then be able to easily access the application via Launchpad or Finder.

**NOTE :** This OTP application is designed for Mac with Apple Silicon (ARM64) processors. MacOS systems with x86\_64 architecture are not supported.

## Sous Linux :

You have three installation formats available, depending on your Linux distribution :

1. NeoOTP.deb : For Debian/Ubuntu based distributions. Double click the file or install the package using the command "sudo dpkg -i NeoOTP.deb" and "sudo apt-get install -f" to resolve dependencies.
2. NeoOTP.rpm : For distributions like Fedora, CentOS, or openSUSE. Double click or install with the command "sudo rpm -i NeoOTP.rpm".
3. NeoOTP.AppImage : Universal and portable executable format. Make it executable with `chmod +x NeoOTP.appimage` then launch it directly without installation. However, it won't integrate properly if you don't use a dedicated tool like AppImageLauncher. If the file doesn't launch, install fuse2: "sudo apt install libfuse2".

## USING THE APPLICATION

- Plug in your NEOWAVE Winkeo or Badgeo and open the application.
- During your first 2FA setup on the service of your choice, retrieve the secret key provided by the service, available as a QR Code or displayable for copying.
- Paste this secret key into the NEOWAVE OTP Manager application's enrollment page (+ button), and enter the account name. Alternatively, import a screenshot of the QR code previously saved on your computer into the application.
- Setup complete! Your OTP code is available on the application's main page. Each time you log in to the service, open the application to retrieve your OTP code.

**NB :** Keep the default values for advanced options unless specific settings are required by the service.

## LICENSE AND ATTRIBUTIONS

### Main Application

NEOWAVE OTP Manager - Distributed under the **BSD 2-Clause License**.

Copyright (c) 2026 NEOWAVE

All rights reserved

Source Code: The source code for this application is available upon request. Contact [contact@neowave.fr](mailto:contact@neowave.fr)